

The Facts About Our...

# Earth Friendly Forklifts

## Required Service

Engine Oil Change  
Engine Oil Filter Change  
Hydraulic Oil Change  
Hydraulic Oil Filter Change  
Steering Axle Greasing  
Attachment Greasing  
Transmission Oil Change  
Transmission Oil Filter Change  
Tilt Cylinder Greasing  
Mast Mounting Greasing  
Gear Oil (final drives) Change  
Brake Fluid Change  
Tires

## Linde (39X Series)

Every 300/1,000 Hours  
Every 300/1,000 Hours  
Every 6,000 Hours  
Every 3,000 Hours  
Every 250 Hours  
Every 250 Hours  
NOT REQUIRED  
NOT REQUIRED  
NOT REQUIRED  
NOT REQUIRED  
NOT REQUIRED  
NOT REQUIRED  
As Needed\*

## Competition (Conventional TC Trucks)

Every 250/500 Hours  
Every 250/500 Hours  
Every 2000 Hours  
Every 2000 Hours  
Every 250 Hours  
Every 250 Hours  
Every 1200/2400 Hours  
Every 1200/2400 Hours  
Every 250 Hours  
Every 250 Hours  
Every 500 Hours  
As Needed  
As Needed

\* Up to three times the life!



**Linde Material Handling  
North America Corporation**  
2450 West 5th North Street  
Summerville, SC 29483  
(843) 875-8000  
trucksales@lmh-na.com  
www.lmh-na.com



Tomorrow's reflection today.

